

GLOSSARY

A

AGL - Above Ground Level

B

BHP - Brake Horse Power

C

°C - Temperature in degrees Centigrade

CAS - Calibrated Airspeed

D

E

F

°F - Temperature in degrees Fahrenheit

F/F - Fuel Flow

G

G, g - Unit of acceleration. One g is the normal acceleration due to gravity

GA - Go-around. Mode of operation of flight

GAL/HR - Gallon of fuel used in one hour

GPH - Gallons Per Hour

H

I

IAS - Indicated Air Speed. Actual reading on panel instrument (airspeed indicator)

IFF - Identification Friend or Foe, interrogation communication equipment.

J

K

KHz - Kilohertz (Kilocycles per second)

KTS - Knots

L

M

MHz - Megahertz (Megacycles per second), 1000 KHz

MPH - Miles Per Hour

N

NAVAID - Integration of communication equipment within and beyond the aircraft

O

OBS - Omni Bearing Selector

P

PSI - Pounds per Square Inch

Q

R

RPM - Revolutions Per Minute

S

T

TCTO - Time Compliance Technical Order

U

V

VHF - Very High Frequency (30 to 300 MHz)

VOR - VHF Omnidirectional Radio Range (Omnirange) (VHF navigation aid)

VVI - Vertical Velocity Indicator

W

X

Y

Z

INDEX

ALPHABETICAL

	Page		Page
A			
Abort	3-2	Cylinder Head Temperature Gauge	5-1
After Landing	2-14	D	
After Takeoff	2-9	Departing a Prepared Surface	3-2
Airspeed Conversion	A-2	Dimensions	1-1
Airspeed Correction	A-3	E	
Airspeed Indicator	1-15	Electrical Fire	3-6
Airspeed Limitations	5-1	Electrical System	1-10
Altimeter	1-15	Emergency Engine Shutdown on the Ground	3-2
Ammeter	1-11	Emergency Ground Egress	3-2
Ammeter	5-4	Engine	1-1
Approach to Field	2-10	Engine Driven Fuel Pump	1-10
Asymmetrical Flaps	3-10	Engine Failure Immediately After Takeoff	3-2
Attitude Indicator	1-15	Engine Fire During Flight	3-5
Auxiliary Fuel Pump	1-10	Engine Instruments	1-6
B			
Before Descent	2-10	Engine Restart During Flight	3-3
Before Landing	2-10	Engine Shutdown	2-14
Before Leaving Aircraft	2-15	Engine Start	7-2
Before Starting Engine	2-4	Engine Warmup	7-2
Before Takeoff	2-6	Exterior Inspection	2-2
Before Taxiing	2-6	External Power Receptacle	1-11
Brake Failure	3-10	F	
Brake System	1-13	Flight Control System	1-14
Braking Procedure	2-13	Flight Controls	6-2
C			
Cabin Doors	1-20	Forced Landing	3-6
Cabin Door Movable Window	1-20	Fuel Flow Indicator	1-6
Cabin Heating and Ventilation System	1-19	Fuel Flow Indicator	5-3
Carbon Monoxide Detector	1-20	Fuel Injection/Air Induction System	1-2
Center of Gravity	A-5	Fuel Quantity Indicator	1-10
Circuit Breakers and Fuses	1-13	Fuel Quantity Indicators	5-3
Climb Performance	6-2	Fuel System	1-7
Climbs	2-9	Full Flap Landing	2-12
Clock	1-16	G	
Cold Weather Operations	7-2	General Flight Characteristics	6-1
Communications/Navigation Equipment	1-16	Go-Around	2-13
Control Lock/Gust Locks	1-14	Gross Weight	1-1
Critical Action Procedures	3-1	GROUND OPERATION EMERGENCIES	3-2
Crosswind Landing	2-13	H	
Cruise and Range Performance	A-8	Heading Indicator	1-16
Cruise Performance	6-2	High Ammeter Reading	3-8
Cruise Performance (10,000 ft)	A-13	Hot Weather Operations	7-2
Cruise Performance (2500 ft)	A-10	I	
Cruise Performance (5000 ft)	A-11	Ice and Rain	7-1
Cruise Performance (7500 ft)	A-12	Ice	7-1
Cylinder Head Temperature	1-6	Idle Descent	6-2

	Page
Ignition Switch	1-2
Ignition System	1-2
IN-FLIGHT EMERGENCIES	3-3
Instrument Flight	7-1
Instrument Markings	5-1
Instruments	1-14
Interior Inspection	2-1
Interior Lighting	1-19
Interphone System	1-16
INTRODUCTION	3-1
Introduction	2-1
Introduction	7-1
Introduction	A-1
 J	
 K	
 L	
LANDING EMERGENCIES	3-10
Landing	2-12
Landing and Taxi Lights	1-19
Landing Distance Table	A-8
Landing On Slippery Runways	2-13
Landing/Taxi Lights	5-4
Landing With a Flat Tire	3-10
Level Off	2-9
Lighting	1-17
Loading Chart	A-5
 M	
Magnetic Compass	1-16
Manifold Pressure & Engine RPM	1-5
Manifold Pressure Gauge	1-6
Manifold Pressure Gauge	5-2
Manual Primer	1-10
Master Switch	1-11
Minimum Crew Requirements	5-1
Mixture Control	1-2
 N	
Navigation Lights	1-17
Negative Ammeter Reading	3-8
Night Flying	7-2
No-Flap Landing	2-12
Noncritical Action Procedures	3-1
Normal Category	5-4
Normal Landing	2-12
Nosewheel Steering System	1-13
 O	
Oil Pressure Gauge	1-7
Oil Pressure Gauge	5-2

	Page
Oil System Malfunction	3-8
Oil system	1-7
Oil Temperature Gauge	1-6
Oil Temperature Gauge	5-1
Operating Limitations	5-1
Optimum Cruise Performance	A-7
Overhead Speaker System	1-16
 P	
Parking Brake	1-13
Partial Engine Failure During Flight	3-4
Pitot Heat	1-15
Pitot Static Malfunction	3-10
Pitot Static System and Instruments	1-14
Prohibited Maneuvers	5-4
Propeller	1-5
Propeller	5-2
Propeller Control Knob	1-6
 Q	
 R	
Rain	7-1
Rate of Climb Data	A-7
Rate of Climb Data, T-41D Model	A-9
Runaway Propeller	3-9
 S	
Seat Belts and Shoulder Harnesses	1-20
Seat Operation	1-20
Short Field Landing	2-13
Short Field Takeoff	2-9
Smoke and Fume Elimination	3-6
Soft Field Landing	2-13
Soft Field Takeoff	2-9
Spins	6-1
Stall Warning Horn	1-14
Stalls	6-1
Starting Engine	2-4
Starting System	1-2
Straight-In Approach	2-13
Strobe Lights	1-19
Structural Damage or Controllability Check	3-9
Suction Gauge	5-3
 T	
Tachometer	1-6
Tachometer	5-2
TAKEOFF EMERGENCIES	3-2
Takeoff	2-8
Takeoff and Landing Crosswind Chart	A-6
Takeoff Data	A-7
Takeoff Data, T-41D Model	A-9

	Page
Takeoff Run	6-2
Taxiing	2-6
The Aircraft	1-1
Throttle	1-2
Throttle Application	2-12
Throttle Linkage Failure	3-10
Touch-and-go Procedures	2-14
Transponder	1-17
Trim System	1-14
Turbulence and Thunderstorms	7-1
Turn-and-Slip Indicator	1-15

U

Utility Category	5-4
------------------------	-----

V

Vacuum System	1-15
Vertical Velocity Indicator (VVI)	1-15
VHF Radio	1-16

VOR Receiver	1-17
--------------------	------

W

Weight and Balance	A-4
Weight Limitations	5-4
Weight Limitations(T-41D)	5-4
Wing Flap System	1-13

X

Y

Z